



6454000211

ENG

VENTILATION FILTER FOR TANK SCREW GLASSFIBRE

SWE

VENTILATIONSFILTER FÖR PÅFYLLNINGSKORK GLASFIBER

FIN

HUOHOTTIMEN SUODATIN ÖLJYTANKKIIN LASIKUITU

6454000315

ENG

FILTER FOR ALUTANK. ALUCAR 500 L

SWE

RETURFILTERPATRON ALUCAR 500 L

FIN

SUODATIN PATRUUNA ALUCAR 500 L

ENG REPLACING FILTER
SWE FILTERBYTE
FIN SUODATTIMEN VAIHTO



Tip!

Clean components with pressure air before replacing filters.
Rengör komponenter med tryckluften innan du byter filter.
Puhdista osat paineilmalla ennen suodattimen vaihtamista.

Oil is being filtered using fast coupling (accessory).
Olja filtreras med hjälp av snabbkopplingen (tillbehör).
Ölly suodattuu käytettäessä pikaliitintä (lisävaruste).

6454000211

- ENG
- SWE
- FIN

VENTILATION FILTER FOR TANK SCREW GLASSFIBRE

VENTILATIONSFILTER FÖR PÅFYLLNINGSKORK GLASFIBER

HUOHOTTIMEN SUODATIN ÖLJYTANKKIIN LASIKUITU



6454000315

- ENG
- SWE
- FIN

FILTER FOR ALUTANK. ALUCAR 500 L
RETURFILTERPATRON ALUCAR 500 L
SUODATIN PATRUUNA ALUCAR 500 L



6454000315

ENG

FILTER FOR ALUTANK. ALUCAR 500 L

SWE

RETURFILTERPATRON ALUCAR 500 L

FIN

SUODATIN PATRUUNA ALUCAR 500 L



6454000860

- ENG
- SWE
- FIN

FILTER TO SIGNAL LINE, PARKER

FILTER, PARKER FÖR SIGNAL LINJEN KOMPLETT

SUODATIN PARKER SIGNAALI LINJAAN TÄYD.

